









# SteriClick™ Pro Touch Wireless Keyboard

Medical grade IP68 waterproof keyboard with Antimicrobial protection



	Cleans with all common non-corrosive medical cleaning solutions certified for medical usage
	2.4GHz digital radio frequency technology with working distance up to 10 meters (30 feet) Automatic synchronization between keyboard and receiver
	IP68 water and dust protection
	Unique antibacterial coating on keyboard and cable preventing micro organisms
	Very comfortable and light typing Low profile keys easy for an easier to clean flat surface with Touchpad – (no mouse required ideal for confined desk space)
	Mini USB receiver
	Compatible with Microsoft Windows 10/8/7/Vista/XP/2000/ME/98, Mac OSX 10.5+
	Plug and play. Easy to install, no drivers needed
<b>Certification:</b>	CE, FCC, ROHS
<b>Layout:</b>	US English 110 Keys
<b>Warranty:</b>	SteriClick provides a Limited One (1) Year Warranty (“Warranty Period”) to the initial purchaser of this product.

# SteriClick™ Pro Touch Wireless Keyboard user guide

Medical grade IP68 waterproof keyboard with Antimicrobial protection

1. **Inserting and replacing the batteries:** Insert two alkaline AAA batteries



into the slot on back of keyboard, observing proper polarity.

2. **Mini USB Wireless receiver 'dongle'** : is located in back of keyboard



3. **Set up your wireless keyboard and mouse**

Follow these instructions to set up your wireless keyboard and mouse before attempting troubleshooting procedures.

- Connect the USB receiver into the USB port on your computer.
  - Restart the computer.
  - Make sure batteries are installed in both the wireless mouse and in the keyboard.
  - Make sure the keyboard is turned on.
4. Only clean keyboard surface with **non-corrosive** cleaning solutions.
  5. **DO NOT** use **Bleach** or **Harsh Chemicals** for cleaning keyboard surface.